



CRAZY CORNER

REQUIREMENTS:

- 2-3 Attendants (Entrance – Back corner – Exit)
- 1 Dedicated 20 amp circuits within 100' - CC&E will provide heavy gauge extension cord.
- Unit Size: 26L x 23W x 12H Indoor Setup Space Required: 28L x 25W x 14H
- Recommended play time: 1 minute
- If outdoors, the temperature needs to be above 45 degrees.
- Max. 4 participants
- Maximum player weight: 150 lbs
- Recommended Participant Ages: K-Middle School
- If indoors, remove center bar in double door and only on ground level. Course can't be taken down stairs indoors or outdoors.
- The course can't be transported further than 100 feet on a dolly.

PLEASE...

- Remove: Shoes; All items from pockets; food, gum or retainers from mouth; eye glasses; hair clips, watches, earrings and necklaces.
- Place items in your shoes after removing your shoes. Parents should hold shoes.
- CC&E is Not responsible for lost or stolen articles.
- Do not enter obstacle course unless Operator is present.
- No dog piling, wrestling, flips or karate kicks.
- Do not: bounce off side walls or entrance way.
- No sitting or standing at top of slide, must continue immediately down slide feet first only.
- Operator can terminate play for not following rules.
- Participants should not engage in a Game if they have any of the following conditions: Current or previous injury to the back or neck; Chronic knee or other joint conditions; Any respiratory conditions, including but not limited to asthma or bronchitis; Any heart related or circulatory conditions or Pregnancy.

OPERATOR AWARENESS:

- WIND CONDITIONS MUST BE LESS THAN 20 MPH; if wind gusts begin, deflate immediately.
- Adult Operators are required for safe use of obstacle course. Instruct participants to stay on their side of the course.
- Operator should point out and make participants aware of the posted warning labels and safety rules.
- Henna is not allowed on the inflatable.
- Operator should remove all debris from the area prior to allowing participants on the inflatable.
- Operator should watch for signs of deflation such as sagging, excessive wrinkling or distortion. If these are observed, they should ask participants to exit the course safely and remain calm, as there is no danger.
- Operator should keep all spectators outside the course and maintain at least a 3 foot perimeter around it.
- Operator must not allow access to the rear of the game or near the inflation blower and power supply.
- Always limit participants to the number specified above. Use good judgment on mix and matching age groups and physical size.
- Stagger number of children entering to maintain a steady flow. Only two participants are allowed on the inflatable at one time.
- If the unit becomes wet, dry the wet area before continuing.
- IMPORTANT – NEVER RUN, LEAP, SKIP, TUMBLE OR BOUNCE OFF ANY INFLATABLE ONTO FLOOR OR GROUND. DOING SO CAN CAUSE SEVERE INJURY!
- Silly string, foam or like products are not permitted in any event where Inflatable Games are being used.
- Duct tape may not be used to secure electrical cords or to post rules on games; consult CC&E for alternatives.

EMERGENCY EXITING:

- If power goes out: DO NOT PANIC; have participants sit down immediately; calmly direct and assist participants to the exit; the designed slow deflation allows plenty of time to exit the unit; DO NOT open the air vents, this will cause rapid deflation.
- Attendant should: a) check that blower is plugged in; b) check to make sure blow tube is attached to blower; c) check to see if zipper is fully zipped.
- Do not allow anyone to enter the slide until it is properly re-inflated and the power supply is stabilized.

Creative Carnivals & Events, LLC. Not Responsible For Loss or Injury.