



GIANT HAMSTER BALL RACING

REQUIREMENTS:

- 2-4 Attendants
- 40L x 30W or 50L x 20W Inflated Track
- 1 Dedicated 20 amp circuit within 100' - CC&E will provide heavy gauge extension cords.
- If indoors, remove center bar in double door for entrance on ground level. The inflatable can't be taken up or down stairs.
- 2 Participants - **Only 1 person in a hamster ball at a time**
- Recommended Participant Ages: Elementary through Adult
- Extra Items: 2 Hamster Balls

NOTE: PLEASE DO NOT DEFLATE HAMSTER BALLS. Deflation of the hamster balls may result in an extra charge.

NOTE: If rented as a single hamster ball with tarp - Tarp is 40' X 60"

Hamster balls race to back of track, turn and race back to entrance. Attendants should be in the back of the lanes to ensure that balls are not pushing and moving track. First team to cross finish line wins. Front and rear attendants ensure balls are not leaving track area.

PLEASE...

- ABSOLUTELY No Sharp Objects Allowed Near the Hamster Ball. Remove: All items from pockets; food, gum or retainers from mouth; eye glasses; watches, hair clips, earrings and necklaces. Place items in safe location or with parents.
- CC&E is Not responsible for lost or stolen articles.
- Do not enter Inflatable Game unless Operator is present.
- Do not: bounce off side walls or entrance way.
- Operator can terminate play for not following rules.
- Participants should not engage in a Game if they have any of the following conditions: Current or previous injury to the back or neck; Chronic knee or other joint conditions; Any respiratory conditions, including but not limited to asthma or bronchitis; Any heart related or circulatory conditions or Pregnancy.

OPERATOR AWARENESS:

- Wind conditions must be less than 20 mph, if wind gusts begin, deflate immediately.
- Adult Operators are required for safe use of Inflatable Games.
- Customer is responsible for any damage that results if balls leave track due to lack of supervision of equipment.
- Operator should point out and make participants aware of the posted warning labels and safety rules.
- Operator should remove all debris from the area prior to allowing participants on the Inflatable Game.
- Operator should watch for signs of deflation such as sagging, excessive wrinkling or distortion. If these are observed, they should ask participants to exit the inflatable safely and remain calm, as there is no danger.
- Operator should keep all spectators outside the Game and maintain at least a 3 foot perimeter around it.
- Operator must not allow access the rear of the game or near the inflation blower and power supply.
- Please use the inflation blower provided to bring the hamster ball up to full inflation again.
- Always limit participants to the number specified above. Use good judgment on mix and matching age groups and physical size.
- Never start a new player until prior player has exited equipment.
- Silly string, foam or like products are not permitted in any event where Inflatable Games are being used. Henna is not allowed on inflatables.
- Duct tape may not be used to secure electrical cords or to post rules on games, consult us for alternatives.
- If power goes out the Attendant should: a.) check that blower is plugged in; b.) check to make sure blow tube is attached to blower; c.) check to see if zipper is fully zipped.

Creative Carnivals & Events, LLC not responsible for loss or injury.