

SNOW CONE MACHINE

REQUIREMENTS:

- 1-8' Table
- 1 2 Attendants
- 1 Dedicated 20 amp circuit within 25 ft and plug into outlet.
- 1-16 Gauge extension cord provided by the customer.
- Adults only to operate machine.
- \bullet CC&E is not responsible for food service items not purchased directly with machine rental.
- For pickup: Machine size is 29" tall x 26" long and 14" wide
- Please note if the machine is picked up, it can not be transported in an open area. We do not allow them unprotected in the back of a truck.

INSTRUCTIONS FOR USE:

- Remove lid from syrup (keep lid) and insert pump into top of syrup container.
- Place ice in top grinder spout. Turn on motor button and gently lower handle on grinder spout and crushed ice will drop into base unit.
- Scoop into cups, pump 1/2 squirt into cup and serve.

CLEANING:

- Dry out base unit. Rinse out syrup pumps and replace lid on syrup containers.
- PLEASE do not throw away syrup containers, pumps or lids. We recycle these so we can bring you the best price for your supplies. We will bill any lost items.

ICE PROVIDED BY CUSTOMER - 25 LBS. PER 100 SERVINGS

Creative Carnivals & Events, LLS not responsible for loss or injury.