



**ADULT HI STRIKER**



**REQUIREMENTS:**

- 1 Attendant
- If outdoors, placement on pavement only. Hi Striker can't be carried up or down stairs.
- If indoors, remove center bar in double door and only on ground level.
- 8L x 5W x 14H Allow 10' depth for a "striking zone" to enable participant to swing the mallet safely.
- 1 Participant
- Recommended Participant Age: Middle school to Adult
- Extra equipment: 1 mallet is provided. Customer will be charged for missing mallet.
- Recommended play: 3 attempts to make the striker hit the bell.

**OPERATOR AWARENESS:**

- Be sure there is adequate clearance between the player and spectators.
- Make sure there is more than enough space to swing the mallet safely.
- Never allow more than one person in the "striking zone" at a time.
- Keep spectators clear from the sides and back of the Hi Striker.
- Regularly inspect mallet to ensure it is in study condition.
- All players must wear shoes.
- Never use the game in strong winds over 20 mph or when there is lightening.
- Silly string, foam or like products are not permitted in any event where inflatable games are being used.

Creative Carnivals & Events, LLC is not responsible for loss or injury.