



**ADULT HI STRIKER**

**REQUIREMENTS:**

- 1 Attendant
- Place on pavement only and can't be carried up stairs.
- 8L x 5W x 14H (Allow 10' depth for a 'striking zone' to enable participant to swing the mallet safely)
- 1 Participant
- Recommended Participant Ages: Middle School to Adult
- Recommended Play: 3 attempts to make the striker hit the bell.

**OPERATOR AWARENESS:**

- Be sure there is adequate clearance between the player and spectators.
- Rope off room to create a 'striking zone.' Make sure there is more than enough space to swing the mallet safely.
- Never allow more than one person in the 'striking zone' at a time.
- Keep spectators clear from the sides and back of the Hi Striker.
- Regularly inspect mallet to ensure it is in sturdy condition.
- All players must wear shoes.
- NEVER USE THE GAME IN STRONG WINDS (over 25 MPH) OR LIGHTNING!
- Silly string or similar products are not permitted at any event where CC&E equipment is being used.
- Duct tape may not be used to post rules on games or inflatables. Please consult CC&E for alternatives.
- Creative Carnivals & Events, LLC is Not Responsible for Loss or Injury.